



# Permanent Water Saving Rules



## Residential and commercial lawns

- Manual watering with a bucket or hand-held hose fitted with a trigger nozzle is permitted at any time
- Watering systems may be used between 6pm and 10am



## Residential and commercial gardens

- Manual watering with a bucket or hand-held hose fitted with a trigger nozzle is permitted at any time
- Watering systems may be used between 6pm and 10am



## Public gardens and lawns

- Manual watering with a bucket or hand-held hose fitted with a trigger nozzle is permitted at any time
- Watering systems may be used between 6pm and 10am but must be fitted with a rain or soil moisture sensor



## Hard surfaces

A high pressure cleaning device, a bucket or hand-held hose fitted with a trigger nozzle may be used:

- in response to an accident, fire, health hazard, safety hazard or other emergency
- to clean staining on a surface no more than once per season (summer, autumn, winter and spring), or
- in the course of construction or renovations



## Vehicles

- Washing with a bucket or hand-held hose fitted with a trigger nozzle is permitted at any time



## Fountains and water features

- Must recirculate water

